



Damage Repair Guidelines

| Damage to Panel Description | Repair Guideline |
|--|--|
| Facer Delaminations | Small Areas: Sheathing Tape (2-7/8-inch Ox Sheathing or equivalent.) Large Areas: Liquid House Wrap (StoGuard or equal) |
| Tears or holes in Thermo-Ply less than 1" in length or diameter (non-structural) | 4" Self-Adhering Flashing Tape meeting AMMA 711-07 (Ox Arctic Flash Flashing Tape, Titan Butyl Flashing or equivalent) |
| Tears or holes greater than 3"up to 8 inches in diameter | Blocking can be min 2x4, above and below damage and apply Self-Adhering Flashing Tape meeting AMAA 711-07 (Arctic Flash Flashing Tape, Titan Butyl Flashing or equal) |
| Tears or holes greater than 8" | Block behind the tear or hole, fasten with proper fasteners, and apply flashing tape over the hole/ tear and fasteners |

^{*}These guidelines should be used with good judgement to ensure sheathing maintains intended structural, moisture, and air barrier requirements.

OX Engineered Products

22260 Haggerty Road Suit 365 Northville, MI 48167 p. 248.289.9950 f. 248.289.9955 oxengineeredproducts.com

^{**}Utility or trade (deliberate penetrations) are not considered damage. Please refer to penetration treatment above.